



T-MAN CHAIN CONVERSION KIT

1.

Grease your stainless steel bolts

2.

Torque the bolts at 35 foot
pounds

3.

Call us with any questions at
336-993-7068

